

Application Instructions

ScanBand® DR PLUS Thermal Wristbands



Lay the sheet on a flat surface - hold the top left corner of the sheet and gently push the wristband through the back of the sheet to remove



Remove the blue tab on the back of the wristband to expose the adhesive



Apply the band around the patient's wrist and secure with adhesive closure - be sure to leave enough room to ensure a comfortable and secure fit

